

Quick start guide

クイック スタート ガイド






neato




What's in the box

セット内容




Quick start guide


- 1 Insert plug behind the charge base. Shorten the cord as needed by wrapping it behind the charge base.



- 2 Select a clear area with good Wi-Fi coverage. Make sure the charge base is against the wall and plugged in.




- 3 Place the robot against the charge base. When docked properly, the battery icon will light up.



- 4 Download the MyNeato application.



- 5 Check your mobile device setting to make sure the Bluetooth is switched on.




- 6 Finish your set up process with the MyNeato application.



Helpful hints


Set up your house

Before the robot starts to vacuum, pick up items that could become tangled, such as cables, socks, and shoelaces. Tuck fringes under rugs.



Keep your charge base secure

Your charge base comes with a pad designed to keep it secure on a hardwood floor. Remove these pads if you plan to place the charge base on carpet.



Clean with the MyNeato app

Use the MyNeato app to:

- Schedule your robot
- View cleaning maps
- Create No-Go Zones



Need assistance?


Learn more about your robot:
www.NeatoRobotics.com/UG

We are here to help. Contact us at:
www.NeatoRobotics.com/contact-us




クイック スタート ガイド


- 1 電源コネクターを充電台の背面にしっかりと差し込んでください。図の様に充電台の背面にコードを巻きつければ、長さを調整することができます。




- 2 Wi-Fi 使用可能エリア内で、充電台の両側および正面に30cmの空間がある壁面のコンセントを選択します。充電台は、壁面を背に固い床の上に設置し、電源を接続します。




- 3 ネイトロボット掃除機の丸い側面を充電台の金属の充電端子にしっかりとめ込んでください。正しく接続されると、バッテリーアイコンが点灯します。




- 4 「MyNeato」アプリケーションをダウンロードしてください。尚、従来の「Neato」アプリケーションとは互換性はありません。



- 5 モバイルデバイスの設定メニューから、Bluetoothが有効になっていることを確認します。




- 6 「MyNeato」アプリケーションを使って、ネイトロボット掃除機のセットアップを完了します。



お役立ち ヒント


お掃除エリアの準備

ロボット掃除機をお使いになる前に、ケーブル、ソックス、靴紐など、床の上に絡まりやすいものがないか確認して、取り除いてください。ラグマットなどの房飾りは内側に折り込んでください。



充電台を安定して設置するために

充電台は、固い床面の上に安定して置ける様に、裏面にパッドを備えています。カーペットなど、柔らかい床面の上に置く場合は、パッドを取り除いてから、設置してください。



MyNeato アプリを使って便利にお掃除

MyNeato でできること。例えば：

- お掃除スケジュールを設定できます
- お掃除エリアのフロアマップを確認できます
- 侵入禁止ゾーンを設定できます



お困りですか？

ネイトロボット掃除機についてもっと知りたい場合は
www.NeatoRobotics.com/UG

質問などがおありの場合、以下のURL からお問い合わせ頂けます：
www.NeatoRobotics.com/contact-us



Neato Robotics®, Inc.
50 Rio Robles
San Jose, CA 95134, USA

NeatoRobotics.com



P/N 515-0079 Rev C